



72-34774 – 72-94138
Air and bug deflector
Installation Instructions

- 1- Clean front of hood area before installing bug shield.
- 2- Place bug shield in position, ensuring the cut-out is centered around the RAM logo and fits tight against the hood.
- 3- Mark the position of the four holes – remove bug shield
- 4- With a 1/4" drill bit carefully drill the marked holes.
- 5- Install shield using the black plugs provided.
 - a. Push black fastener securely into hole.
 - b. Lock in place by firmly pressing key into the fastener.
- 6- Do not attach the clear rubber bump-ons to the shield or the warranty will be voided. It is essential for the clear rubber bump-ons to be attached to the vehicle hood or damage will occur. Use the alcohol prep pads to clean the area, where the shield touches the vehicle, large enough to affix the rubber bump-ons. Gently hold the shield away from the hood and place the bump-ons on the vehicle, between the shield and hood. Make certain that the bump-ons are positioned to keep the shield from contacting hood.

Cleaning instructions:

Wash with warm water and a mild soap solution using a soft cloth or sponge. Use of cleaners not approved for acrylic or use of improper solvents could result in permanent damage which will not be covered by the warranty.

WARNING: This bug shield is made of a breakage resistant material, but the avoid damage machine car washes are not advised.

4 – 5935 Push Pin, 8-Bump-ons, 1-Alcohol Pad

www.wadeauto.com
www.westinautomotive.com



72-34774 – 72-94138
Air and bug deflector
Installation Instructions

- 1- Clean front of hood area before installing bug shield.
- 2- Place bug shield in position, ensuring the cut-out is centered around the RAM logo and fits tight against the hood.
- 3- Mark the position of the four holes – remove bug shield
- 4- With a 1/4" drill bit carefully drill the marked holes.
- 5- Install shield using the black plugs provided.
 - a. Push black fastener securely into hole.
 - b. Lock in place by firmly pressing key into the fastener.
- 6- Do not attach the clear rubber bump-ons to the shield or the warranty will be voided. It is essential for the clear rubber bump-ons to be attached to the vehicle hood or damage will occur. Use the alcohol prep pads to clean the area, where the shield touches the vehicle, large enough to affix the rubber bump-ons. Gently hold the shield away from the hood and place the bump-ons on the vehicle, between the shield and hood. Make certain that the bump-ons are positioned to keep the shield from contacting hood.

Cleaning instructions:

Wash with warm water and a mild soap solution using a soft cloth or sponge. Use of cleaners not approved for acrylic or use of improper solvents could result in permanent damage which will not be covered by the warranty.

WARNING: This bug shield is made of a breakage resistant material, but the avoid damage machine car washes are not advised.

4 – 5935 Push Pin, 8-Bump-ons, 1-Alcohol Pad

www.wadeauto.com
www.westinautomotive.com