



Non Drill BUG DEFLECTOR
Nissan Pathfinder 1996 - 1999
Installation Instructions

- 1) Thoroughly clean front hood area. Open hood.
- 2) Carefully remove weather stripping by taking out plastic rivets on the underside of hood.
- 3) Carefully slide the clips over the bugshields and sheet metal of hood, MAKING SURE the BARBED side of the clips grips the shield.
- 4) Reinstall weather stripping. NOTE: not all plastic rivets can be reinstalled. Slowly close the hood and check for sufficient clearance between the bugshield and the grill. DO NOT HOLD BUGSHIELD WHEN CLOSING THE HOOD.
- 5) DO NOT ATTACH THE CLEAR BUMP-ONS TO THE BUGSHIELD. DOING SO WILL RESULT IN PAINT DAMAGE THAT WILL NOT BE COVERED BY THE WARRANTY. With the alcohol pad provided clean 6-8 areas behind the bugshield large enough to affix the bump-on.
- 6) Starting on either end of the shield gently pull the bugshield away from the hood and place the bump-on between the hood and the bugshield. BE SURE TO INSTALL ON TO THE HOOD. Now go to the opposite end of the shield and do the same thing.
- 7) Simulate the wind by gently pushing on the bugshield. Where the shield touches the hood place a bump-on there. Go to the opposite side and do the same thing again. Continue until you are certain that the bump-on are positioned to keep the bugshield from contacting the hood.
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- U clips, 1- set of 8 bump-ons

www.wadeauto.com
www.westinautomotive.com



Non Drill BUG DEFLECTOR
Nissan Pathfinder 1996 - 1999
Installation Instructions

- 1) Thoroughly clean front hood area. Open hood.
- 2) Carefully remove weather stripping by taking out plastic rivets on the underside of hood.
- 3) Carefully slide the clips over the bugshields and sheet metal of hood, MAKING SURE the BARBED side of the clips grips the shield.
- 4) Reinstall weather stripping. NOTE: not all plastic rivets can be reinstalled. Slowly close the hood and check for sufficient clearance between the bugshield and the grill. DO NOT HOLD BUGSHIELD WHEN CLOSING THE HOOD.
- 5) DO NOT ATTACH THE CLEAR BUMP-ONS TO THE BUGSHIELD. DOING SO WILL RESULT IN PAINT DAMAGE THAT WILL NOT BE COVERED BY THE WARRANTY. With the alcohol pad provided clean 6-8 areas behind the bugshield large enough to affix the bump-on.
- 6) Starting on either end of the shield gently pull the bugshield away from the hood and place the bump-on between the hood and the bugshield. BE SURE TO INSTALL ON TO THE HOOD. Now go to the opposite end of the shield and do the same thing.
- 7) Simulate the wind by gently pushing on the bugshield. Where the shield touches the hood place a bump-on there. Go to the opposite side and do the same thing again. Continue until you are certain that the bump-on are positioned to keep the bugshield from contacting the hood.
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- U clips, 1- set of 8 bump-ons

www.wadeauto.com
www.westinautomotive.com