



INSTALLATION INSTRUCTIONS

APPLICATION: 1988-1998 CHEVY C/K PICKUP
1992-1994 CHEVY C/K BLAZER
1995-1999 CHEVY TAHOE

**SPORTSMAN
TAILLIGHT
GUARD**
39-3005

**CAUTION:
BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY**

HARDWARE KIT: 8 ea. # 8 x 3/4" Self-Tapping Screws

STEP 1: There are left and right side TailLight Guards. These parts attach to inside of rear hatch/door jamb using self tapping hex screws provided in parts kit, while the outer portion which wraps around side of taillight lens rests against taillight on rubber bumper.

STEP 2: Position appropriate Guard in center of taillight lens with formed mounting bracket tight against inside hatch/door jamb. While holding in position, slowly and carefully close door or hatch to make sure there is adequate clearance for rear door(s) to operate without touching TailLight Guard. Once adequate clearance is achieved, mark locations of holes in bracket onto jamb. Center punch where marked.

STEP 3: Drill where marked using #7 drill bit. Attach Guard using screws provided but do not overtighten and possibly strip threads.

STEP 4: Repeat procedure on opposite side. Installation is complete.

