



INSTALLATION INSTRUCTIONS

APPLICATION: 1999-2000 CHEVY SILVERADO PICKUP
1999-2000 GMC SIERRA PICKUP

**SPORTSMAN
TAILLIGHT
GUARD**
39-3035

**CAUTION:
BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY**

HARDWARE KIT: None Required

STEP 1: Open tailgate to gain access to tailgate jamb. Carefully remove two existing (one upper and one lower) taillight attachment screws, but do not discard as they will be re-used for installation. Gently pull taillight housing out, separating it from body, and let it hang from wiring.

STEP 2: Attach TailLight Guard to taillight, aligning holes in mounting brackets on TailLight Guard with those existing in taillight housing, and slide outer support bracket welded to TailLight Guard into plastic housing.

STEP 3: Secure TailLight Guard/taillight housing assembly to vehicle, re-using factory screws removed in Step 1. Tighten snugly but use caution to avoid cracking housing assembly. Installation is complete.

