



INSTALLATION INSTRUCTIONS

APPLICATION: 1994-2000 DODGE RAM

**SPORTSMAN
TAILLIGHT
GUARD
39-3065**

**CAUTION:
BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY**

HARDWARE KIT: 4 ea. Phillip Head Screws

STEP 1: Open tailgate of vehicle to expose screws.

STEP 2: Remove the upper and lower screws of the taillight assembly.

STEP 3: Align the TailLight Guard with the taillight and attach using the supplied screws.

STEP 4: Repeat for left TailLight Guard.

NOTE: The TailLight Guards are made to fit snug on the vehicle. As the screws are tightened, the metal plates will become flush with the body. If the rubber bumper is too tight against the body, slightly bend the metal plate to loosen.

STEP 5: IMPORTANT - Slowly close the tailgate to check adequate clearance for the TailLight Guards, realign if necessary.

