



INSTALLATION INSTRUCTIONS

APPLICATION: 1997-2000 FORD F150/F250
REGULAR DUTY WIDESIDE PICKUP
1999-2000 F250/F350 SUPERDUTY PICKUP

**SPORTSMAN
TAILLIGHT
GUARD**
39-3095

CAUTION:
**BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY**

HARDWARE KIT: 8 ea. #8 Self-Tapping Tek Screws

STEP 1: Open tailgate fully to access jamb area.

STEP 2: Take appropriate TailLight Guard and center over taillight lens, with rubber bumper snug against the body panel. In some cases, it will be necessary to slightly bend by hand the mounting bracket in order for the bumper to “tension” against the body.

STEP 3: It is advisable to have help while drilling and mounting the Guards in order to avoid installing the Guards incorrectly or “crooked” on your Ford truck. With helpers’ assistance, hold TailLight Guard in position and carefully attach and secure Guard, one screw at a time, until all four have been attached. Carefully close tailgate and make sure TailLight Guard does not interfere with operation of tailgate opening and closing.

STEP 4: Repeat steps 1 through 3 on opposite side of truck. Installation is complete.

