



# INSTALLATION INSTRUCTIONS

APPLICATION: 2000 FORD EXCURSION

**NOTE:** YOUR NEW TAILLIGHT GUARDS REQUIRE **NO DRILLING** FOR INSTALLATION.

## SPORTSMAN TAILLIGHT GUARD

**39-3115**

**CAUTION:**  
BEFORE BEGINNING  
INSTALLATION  
PROCEDURE,  
READ THROUGH  
INSTRUCTIONS  
CAREFULLY AND  
COMPLETELY

**HARDWARE KIT:** 4 ea. Sheet Metal Screws

**STEP 1:** NOTE: DRIVER AND PASSENGER SIDE TAILLIGHTS ARE SLIGHTLY DIFFERENT. TO AVOID MISMATCHING PARTS, CHECK BOTH GUARDS ON ONE SIDE ONLY TO DETERMINE WHICH IS WHICH. Open rear doors to access jamb area and factory taillight attachment screws. Remove screws from housing.

**STEP 2:** Position TailLight Guard over taillight, aligning hollow tubes on Guard with holes exposed where factory screws were removed in Step 1. Using 3" long screws provided in hardware kit, secure TailLight Guard to taillight. Tighten screws firmly.

**STEP 3:** Repeat Steps 1 and 2 on opposite side of truck. Carefully close rear door and check to make sure Guards do not interfere with door. After making sure TailLights allow adequate clearance, tighten all screws (2 per side) completely. Installation is complete.

