



INSTALLATION INSTRUCTIONS

APPLICATION: 1999-2000 JEEP GRAND CHEROKEE

**SPORTSMAN
TAILLIGHT
GUARD**
39-3125

CAUTION:
**BEFORE BEGINNING
INSTALLATION
PROCEDURE,
READ THROUGH
INSTRUCTIONS
CAREFULLY AND
COMPLETELY**

HARDWARE KIT: 2 ea. # 8 x 3/4" Self-Tapping Tek Screws

STEP 1: Open rear hatch to access rear taillight lens and housing. Remove but do not discard the factory screws (2) using Phillips Screwdriver, then carefully pull on housing until it is freed from vehicle.

STEP 2: Position appropriate TailLight Guard over housing/lens assembly and align holes in upper and lower mounting tabs in Guard with those in taillight. Run factory screws through tabs and housing and while holding entire assembly in place, attach bottom tab to housing using #8 self-tapping tek screw provided. Make sure Guard is aligned properly and housing butts against bottom tab before tightening screw provided.

STEP 3: Remove factory screws, then re-insert housing into position onto hatch jamb and snapping into place. Secure housing and Guard assembly to jamb using factory screws removed in Step 1. Repeat Steps 1 through 3 on opposite side. Installation is complete.

