



INSTALLATION INSTRUCTIONS


APPLICATION: 1999-2002 CHEVY TRACKER

AUTOMOTIVE PRODUCTS, INC.

<p>SAFARI BAR ASSEMBLY</p> <p>30-0020 30-0025</p> <p>MOUNT KIT:</p> <p>30-1275</p>	
---	--

QTY	PARTS KIT CONTENTS DESCRIPTION	TOOLS REQUIRED
1	SAFARI BAR ASSEMBLY (PURCHASED SEPARATELY)	3/4" SOCKET
1	MOUNT BRACKET - DRIVER SIDE	17MM SOCKET
1	MOUNT BRACKET - PASSENGER SIDE	RATCHET
2	1/2-13 X 2.00" HEX HEAD BOLT	TORQUE WRENCH
2	1/2" FLAT WASHER	17MM WRENCH
2	1/2" LOCK WASHER	

- STEP 1. Remove the contents from the box and check for any damage. Verify all parts against the parts list.
- STEP 2. Read and understand instructions completely before beginning installation.
- STEP 3. Determine Driver and Passenger Mount Brackets from figure above.
- STEP 4. Remove outside/front bolt from the front cross member. Loosen the rear bolt to sufficiently clear the bracket.
DO NOT REMOVE COMPLETELY.
CAUTION: Weight of vehicle must be on wheels during installation.
- STEP 5. Slide appropriate Safari Bar Mount Bracket onto rear bolt. Reinstall front bolt and tighten both hand tight.
Repeat for opposite side of vehicle.
- STEP 6. Attach Safari Bar to Mount Brackets using the 1/2" fasteners. Tighten hand tight.
- STEP 7. Center and level the Safari Bar. Tighten and torque fasteners to:
 - 1/2" fasteners 65 Ft. Lbs.
 - 17mm fasteners68 Ft. Lbs.



Finish protection - Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax (pure carnauba, for example) on a regular basis. The use of cleaner wax or any compound which contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.



Westin Automotive Products, Inc.
5200 N. Irwindale Ave. Suite 220
Irwindale, Ca. 91706

Thank You for choosing Westin products
For additional installation assistance please call
Customer service (800) 793-7846 or (507) 375-3559