



INSTALLATION INSTRUCTIONS

APPLICATION: 1999½-2000 NISSAN PATHFINDER

AUTOMOTIVE PRODUCTS, INC.

<p>SAFARI BAR ASSEMBLY</p> <p>30-0025</p> <p>MOUNT KIT:</p> <p>30-1115</p>	
--	--

QTY	PARTS KIT CONTENTS DESCRIPTION	TOOLS REQUIRED
1	SAFARI BAR ASSEMBLY (PURCHASED SEPARATELY)	3/4" SOCKET 14MM SOCKET RATCHET TORQUE WRENCH
1	MOUNT BRACKET - DRIVER SIDE	
1	MOUNT BRACKET - PASSENGER SIDE	
2	1/2-13 X 2.00" HEX HEAD BOLT	
2	1/2" FLAT WASHER	
2	1/2" LOCK WASHER	

- STEP 1. Remove the contents from the box and check for any damage. Verify all parts against the parts list.
- STEP 2. Read and understand instructions completely before beginning installation.
- STEP 3. Determine Driver and Passenger Mount Brackets from figure above.
- STEP 4. Remove the six (6) screws from the lower part of the bumper that secure the plastic shroud. Move plastic out of the way to gain access to the tow hook bolts.
- STEP 5. Locate the 10mm bolts on the side of the frame that secure the tow hook.
- STEP 6. Remove the two (2) front bolts from each side, install the bracket, and replace the bolts.
- STEP 7. Attach Safari Bar to Mount Brackets using the ½" hardware. Leave loose.
- STEP 8. Center and level the Safari Bar. Tighten and torque fasteners to:
 - 10mm Bolts 35 Ft. Lbs.
 - ½" fasteners 65 Ft. Lbs.
- STEP 9. Re-install the screws that secure the plastic shroud.

Finish protection - Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax (pure carnauba, for example) on a regular basis. The use of cleaner wax or any compound which contains an abrasive is detrimental, as the compound will scratch the finish and open it to corrosion.



Westin Automotive Products, Inc.
 5200 N. Irwindale Ave. Suite 220
 Irwindale, Ca. 91706

Thank You for choosing Westin products
 For additional installation assistance please call
 Customer service (800) 793-7846 or (507)-375-3559