



INSTALLATION INSTRUCTIONS

APPLICATION:

2014-2015 Toyota Tundra

AUTOMOTIVE PRODUCTS,

PART NUMBER:

58-171415/58-17141R

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	6	1/2" x 3 1/2" BOLT	10MM SOCKET
2	6	1/2" NUT	17MM SOCKET
3	4	M8-1.25 x 14 MM CAPSCREW	3/4" SOCKET
			14MM WRENCH
			RATCHET

REMOVAL

1. Disconnect the factory fog light harness from the fog lights if equipped (Image 1).
2. Remove the plastic clips in the front inner fender well at the frame and the philips head screws located in the inner fender wells. Remove the lower plastic inner fender (Image 2).
3. Remove the 3 screws that hold the plastic on the bottom of the bumper (Image 3).
4. Remove the factory tow hooks using a 17 mm socket and ratchet.
5. Use a 14 mm wrench to loosen the 8 nuts that attach the bumper to the frame (Image 4)
6. Remove the bumper from the truck.



Image 1



Image 2



Image 3



Image 4



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846

INSTALLATION

1. Attach the frame brackets to the frame using the 8 factory nuts and the factory tow hook bolt.
2. Carefully lift the bumper and slide the mounts into the channels of the frame brackets.
3. Install the supplied 1/2"x3-1/2" bolts and 1/2" nuts through the slots in the frame brackets and the mounts.
4. Adjust the bumper to achieve proper alignment.
5. Tighten all hardware.



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773