



Platinum Series Bug Shield

Installation Instruction: K

It is VITAL that you read and follow these instructions BEFORE you begin installation. Failure to do so can result in damage to your hood which will NOT be covered by the warranty.

- 1) Thoroughly clean front hood area. Open hood.
- 2) Remove gasket above headlights by removing the factory plugs.  
(Your new bugshield eliminates the need for the gasket).
- 3) Place the nylon insert "locking plugs" into the two OUTSIDE holes.

**DO NOT PUSH IN THE LOCKING DEVICE YET**

- 4) Mark the position of the inside holes. Remove the outside "plugs" and remove shield from vehicle.
- 5) With a 1/8" drill bit, carefully drill the two outside holes. **IMPORTANT:** Take care not to drill through or damage the top of the hood.
- 6) Place shield back on vehicle and re-insert the two outside "plugs".
- 7) Screw in (by hand) the screws with the supplied washers .

**DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 8) Push in the locking device on the two outside "plugs".
- 9) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- #10 x1/2 Phillips Truss, 3- Grommets, 2- 5935 Push Pins  
www.wadeauto.com  
www.westinautomotive.com



Platinum Series Bug Shield

Installation Instruction: K

It is VITAL that you read and follow these instructions BEFORE you begin installation. Failure to do so can result in damage to your hood which will NOT be covered by the warranty.

- 1) Thoroughly clean front hood area. Open hood.
- 2) Remove gasket above headlights by removing the factory plugs.  
(Your new bugshield eliminates the need for the gasket).
- 3) Place the nylon insert "locking plugs" into the two OUTSIDE holes.

**DO NOT PUSH IN THE LOCKING DEVICE YET**

- 4) Mark the position of the inside holes. Remove the outside "plugs" and remove shield from vehicle.
- 5) With a 1/8" drill bit, carefully drill the two outside holes. **IMPORTANT:** Take care not to drill through or damage the top of the hood.
- 6) Place shield back on vehicle and re-insert the two outside "plugs".
- 7) Screw in (by hand) the screws with the supplied washers .

**DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 8) Push in the locking device on the two outside "plugs".
- 9) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- #10 x1/2 Phillips Truss, 3- Grommets, 2- 5935 Push Pins  
www.wadeauto.com  
www.westinautomotive.com