



Platinum Series Bug Shield

No Drill BUG DEFLECTOR  
Installation Instruction: L

- 1) Thoroughly clean front hood area. Open hood.
- 2) Place shield in position ensuring it is centered.
- 3) Hold each end of shield securely in place and mark the position of the holes.
- 4) CAREFULLY drill the marked holes with a 1/8" drill bit.

**IMPORTANT: Take care not to drill through or damage the top of the hood.**

- 5) Place shield back into place and install it using the screws and grommets provided.

**DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 6) Slowly lower hood and check for sufficient clearance between the shield and the grill.
- 7) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- #10 X 1/2 Phillips Truss, 4- Grommets

[www.wadeauto.com](http://www.wadeauto.com)

[www.westinautomotive.com](http://www.westinautomotive.com)



Platinum Series Bug Shield

No Drill BUG DEFLECTOR  
Installation Instruction: L

- 1) Thoroughly clean front hood area. Open hood.
- 2) Place shield in position ensuring it is centered.
- 3) Hold each end of shield securely in place and mark the position of the holes.
- 4) CAREFULLY drill the marked holes with a 1/8" drill bit.

**IMPORTANT: Take care not to drill through or damage the top of the hood.**

- 5) Place shield back into place and install it using the screws and grommets provided.

**DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 6) Slowly lower hood and check for sufficient clearance between the shield and the grill.
- 7) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- #10 X 1/2 Phillips Truss, 4- Grommets

[www.wadeauto.com](http://www.wadeauto.com)

[www.westinautomotive.com](http://www.westinautomotive.com)