



Platinum Series Bug Shield  
Installation Instruction: PP

Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two inside holes.

- 1) Thoroughly clean front hood area. Open hood and clean underside where tape will adhere.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will help verify if you have the correct shield for your vehicle).
- 3) Install the two outside screws (using the two bigger screws) into the corresponding, pre-existing holes. **DO NOT OVER TIGHTEN.**
- 4) Hold bugshield securely in place and lower hood to determine that the shield is centered. Do so by "eyeballing" either end. Make adjustments as needed.
- 5) **VERY IMPORTANT:** Pull the center of the shield toward the front of the vehicle until the contours of the shield match the contours of the hood. Clean with the alcohol pad provided. Remove masking and hold in position until tape adheres to hood.
- 6) We have also provided you with two screws and grommets. These are provided as a secondary installation. The 3M tape has been developed and formulated specifically for the automotive market. If you feel the tape will not be enough carefully drill a hole in the appropriate place with a 1/8" drill bit

**IMPORTANT:** Take care not to drill through or damage the top of hood.

- 7) Using a screw driver install the last two screws.

#### **DO NOT OVER TIGHTEN SHIELD.**

- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 x 1/2 BAS screws, 2- 5/16 washers, 2- #10 X1/2 phillips truss, 2- Grommets  
Tape on inside tags

[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)



Platinum Series Bug Shield  
Installation Instruction: PP

Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two inside holes.

- 1) Thoroughly clean front hood area. Open hood and clean underside where tape will adhere.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will help verify if you have the correct shield for your vehicle).
- 3) Install the two outside screws (using the two bigger screws) into the corresponding, pre-existing holes. **DO NOT OVER TIGHTEN.**
- 4) Hold bugshield securely in place and lower hood to determine that the shield is centered. Do so by "eyeballing" either end. Make adjustments as needed.
- 5) **VERY IMPORTANT:** Pull the center of the shield toward the front of the vehicle until the contours of the shield match the contours of the hood. Clean with the alcohol pad provided. Remove masking and hold in position until tape adheres to hood.
- 6) We have also provided you with two screws and grommets. These are provided as a secondary installation. The 3M tape has been developed and formulated specifically for the automotive market. If you feel the tape will not be enough carefully drill a hole in the appropriate place with a 1/8" drill bit

**IMPORTANT:** Take care not to drill through or damage the top of hood.

- 7) Using a screw driver install the last two screws.

#### **DO NOT OVER TIGHTEN SHIELD.**

- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 x 1/2 BAS screws, 2- 5/16 washers, 2- #10 X1/2 phillips truss, 2- Grommets  
Tape on inside tags

[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)