



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: UU

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will help verify if you have the correct shield for your vehicle).
- 3) Starting with the center tab, push "christmas tree plug " (CTP) through shield and into corresponding pre-existing hole.
- 4) Insert the two remaining CTPs.
- 5) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- 5710 CTP Push Pin

www.wadeauto.com
www.westinautomotive.com



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: UU

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will help verify if you have the correct shield for your vehicle).
- 3) Starting with the center tab, push "christmas tree plug " (CTP) through shield and into corresponding pre-existing hole.
- 4) Insert the two remaining CTPs.
- 5) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- 5710 CTP Push Pin

www.wadeauto.com
www.westinautomotive.com