# INSTALLATION INSTRUCTIONS



**Complete Kit: 57-81135** HLR Hoop: 57-81095A Parts Kit: 57-81135B

#### CONTENT


| ITEM | QUANTITY | DESCRIPTION                                | TOOLS NEEDED       |
|------|----------|--|--------------------|
| 1    | 1        | Hoop/Screen Assembly (Packaged Separately) | 10 mm Wrench       |
| 2    | 1        | Mounting Bracket (Driver's Side)           | 10 mm Socket       |
| 3    | 1        | Mounting Bracket (Passenger's Side)        | 1/4" Drive Ratchet |
| 4    | 2        | M12 Bolt Plate Long                        | 3/8" Drive Ratchet |
| 5    | 2        | M12 Bolt Plate Short                       | 13mm Socket        |
| 6    | 4        | M8 Hex Head Bolt Long                      | 13mm Wrench        |
| 7    | 4        | M8 Hex Nut Nylock                          | 19mm Wrench        |
| 8    | 8        | M8 Flat Washer Large                       |                    |
| 9    | 4        | M12 Hex Nut                                |                    |
| 10   | 4        | M12 Lock Washer                            |                    |
| 11   | 4        | M12 Flat Washer                            |                    |
| 12   | 2        | M12 Fish Wire                              |                    |
| 13   | 4        | M12 Plastic Retainers                      |                    |

**NOTE:** Hoop/Screen Assembly packaged separately.


# **PROCEDURE**

1. Remove contents from box, verify if all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.


Failure to identify damage before installation could lead to a rejection of any claim.




1




2. Towards the front of the bed, locate the holes on the bed that will be used to mount the HLR Rack and remove plastic plugs if present. See **Figure 1.** 



- 3. Insert short M12 bolt plate into side hole of the bed through the stake pocket. Thread one of the supplied M12 plastic retainers on to bolt plate to keep it from falling into the hole. See **Figure 2**.
- 4. Thread supplied fish wire on the long M12 bolt plate. Then insert through the back (between cab and bed of the truck) of the front hole shown in **Figure 1.** Thread one of the supplied M12 plastic retainers on to bolt plate to keep it from falling into the hole.
- 5. Locate mounting bracket Item 2 and insert hardware according to Figure 3.
- 6. Hand tighten hardware only for now. All hardware will be fully tightened at the end of installation.







7. Repeat steps 2-6 on passenger's side.


ECO #: W20-0113

8. Position Hoop/Screen Assembly Item 1 on bracket cradles according to Figure 4.



9. Using supplied M8 hardware, fasten Item 1 on to brackets. See Figure 5.





10. Once all components are positioned as desired. Tighten all M8 hardware to 15-18 ft-lbs and all M12 to 50-55 ft-lbs. Note: When tightening M8 hardware that was used to install hoop and screen assembly on step 9, push the top of the HLR rack towards the cab of the truck to maintain straight while tightening.

## **INSTALLATION COMPLETE**







# **WARNING**



Failure to follow these instructions could lead to death, personal injury, and / or property damage.

Failure to follow these instructions could lead to death, personal injury, and / or property damage.

### **FASTENERS:**

All Westin supplied fasteners must be utilized and installed in accordance with the installation instructions and apply torque to the specifications as defined. DOUBLE CHECK ALL FASTENERS BEFORE INITIAL USE, AND PERIODICALLY IN THE FUTURE TO ENSURE PROPER FUNCTION AND SAFETY.

# **DRILLING:**

Most Westin products do not require drilling for installation. If drilling is defined as required, use caution when drilling a vehicle. FAILURE TO REVIEW AN AREA TO BE DRILLED MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.

### **EYE PROTECTION:**

ALWAYS WEAR SAFETY GLASSES OR GOGGLES DURING THE INSTALLATION PROCESS TO AVOID PERSONAL INJURY.

### **MAXIMUM TOWING/CARRYING CAPACITY:**

The Westin Receiver Hitches will have a visible tow rating label affixed directly on the product. User should never exceed the vehicle manufacturers maximum tow and weight rating regardless of the capacity of the hitch. FAILURE TO FOLLOW THESE GUIDELINES WILL VOID THE WESTIN WARRANTY AND MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.

